## MILCON P-725, PUMP STATION UPGRADES

MCAS NEW RIVER, JACKSONVILLE, NORTH CAROLINA NAVAL FACILITIES ENGINEERING COMMAND ~ MID-ATLANTIC DIVISION MARINE CORPS NC IPT ENGINEERING DEPARTMENT









A/E CONTRACT CONTRACT NO: N40085-06-D-8009 WORK ORDER NO. 859348


264
GREENVILLE WASHINGTON LAKE MATTAMUSKEET
(264) PANILLY C. N. S. A.
PAMILICO RIVER  33  33  CAPE  HATTERAS
70  CAPE HATTERAS
NEW BERN (55)
THE USE RIVER OF THE PARTY OF T
JACKSONVILLE TO STANFILL OCEAN
CHERRY POINT
MCB CAPE LOOKOUT
NEW RIVER MARINE CORPS AIR STATION
PLAN NORTH
VICINITY MAP


	_		NDEX OF DRAWINGS				
SHEET NO	NAVFAC NO	DWG NO	SHEET TITLE				
GENERAL	-						
1	12556435	G-001	TITLE SHEET, INDEX OF DRAWINGS				
2	12556436	G-002	GENERAL NOTES				
CIVIL							
3	12556437	C-001	CIVIL NOTES, LEGEND AND ABBREVIATIONS				
4	12556438	C-101	DRAINAGE PLAN & DETAIL				
STRUCTU	JRAL						
5	12556439	S-001	STRUCTURAL NOTES, LEGEND AND ABBREVIATIONS				
6	12556440	S-401	PUMP STATION PAD PLAN				
7	12556441	S-402	PIPE CROSS-OVER PLAN				
8	12556442	S-501	MISCELLANEOUS DETAILS				
MECHANI	CAL						
9	12556443	M-001	MECHANICAL NOTES, LEGEND AND ABBREVIATIONS				
10	12556444	MD401	PUMP PAD DEMOLITION				
11	12556445	M-402	PUMP STATION PLAN				
12	12556446	M-403	SECTIONS				
13	12556447	M-501	DETAILS AND PIPE SUPPORTS				
14	12556448	M-601	FLOW DIAGRAM, SCHEDULE AND SEQUENCE OF CONSTRUCTION				
15	12556449	MD901	PHOTOGRAPHS				
ELECTRIC	CAL						
16	12556450	E-001	ELECTRICAL NOTES, LEGEND AND ABBREVIATIONS				
17	12556451	E-401	PUMP PAD AND SITE PLANS				
18	12556452	E-402	TRUCK LOADING AND PUMP PAD PLANS				
19	12556453	E-501	CONTROL RACK DETAILS AND PLC CONNECTIONS				
20	12556454	E-601	SCHEDULES AND ONE-LINE DIAGRAM				
21	12556455	E-602	PUMP PAD CLASSIFICATION, DETAILS & WIRING DIAGRAMS				





IRE PROTECTION BRANCH MANAGER ODE ID. NO. 80091 | SIZE | D CALE: AS NOTED WORK ORDER NO. 859348 NAVFAC DRAWING NO. 12556435 AUSTIN BROCKENBROUGH & ASSOCIATES, L.L.P. DRAWFORM REVISION: 6 AUG 2007

































- 2. PUMPS START BY DEPRESSING THE PUSHBUTTON AND STOP BY DEPRESSING THE PUSHBUTTON OR BY THE PLC WHEN THE PUMP H-O-A SWITCH IS IN "AUTO".
- 3. IF THE PRODUCT LEVEL IN A BULK STORAGE TANK WITH AN OPEN "ISSUE" MOV FALLS BELOW THE LOW LEVEL SET POINT, THE TRANSFER PUMP SHALL NOT START, AND SHALL BE DISABLED IF RUNNING. NO TRANSFER PUMP CAN START OR BE RE-STARTED UNTIL THE ALARM IS ACKNOWLEDGED AND THE LOW LEVEL CONDITION NO LONGER EXISTS, OR ANOTHER TANK IS SELECTED THAT IS NOT IN AN ALARM CONDITION.
- 4. IF THE PRODUCT LEVEL IN A BULK STORAGE TANK WITH AN OPEN "RECEIPT" MOV RISES ABOVE THE HIGH-HIGH LEVEL SET POINT, THE TRANSFER PUMP SHALL NOT START, AND SHALL BE DISABLED IF RUNNING. NO TRANSFER PUMP CAN START OR BE RE-STARTED UNTIL THE THE ALARM IS ACKNOWLEDGED AND THE HIGH-HIGH LEVEL CONDITION NO LONGER EXISTS, OR ANOTHER TANK IS SELECTED THAT IS NOT IN AN ALARM CONDITION.
- 5. TO CONDUCT A PIPELINE TRANSFER OPERATION TO SYSTEM A/B OR C/D, ALIGN MANUAL VALVES TO ALLOW A TRANSFER FROM THE SOURCE TANK TO THE RAPID REFUEL AREA. ON THE OPERATOR'S PANEL, TURN DESIRED TANK SELECTOR SWITCH TO "ISSUE" AND THE PUMP SELECTOR SWITCH TO "TRANSFER". WITH THE PUMP H-O-A SWITCH IN "AUTO". START THE TRANSFER BY DEPRESSING THE START PUSHBUTTON ON THE OPERATOR' PANEL. THE PUMP SHALL START AND REMAIN IN OPERATION SUBJECT TO THE ALARM CONDITIONS LISTED ABOVE. TO END THE TRANSFER OPERATION, DEPRESS THE "STOP" PUSHBUTTON ON THE OPERATOR'S PANEL.
- 6. TO CONDUCT A TANK-TO-TANK TRANSFER OPERATION, ALIGN THE MANUAL VALVES TO ALLOW A TRANSFER FROM THE SOURCE TANK TO THE DESTINATION TANK. ON THE OPERATOR'S PANEL, TURN SOURCE TANK SELECTOR SWITCH TO "ISSUE", THE DESTINATION TANK SELECTOR SWITCH TO "RECEIVE" AND THE PUMP SELECTOR SWITCH TO "TRANSFER". WITH THE PUMP H-O-A SWITCH IN "AUTO", START THE TRANSFER BY DEPRESSING THE START PUSHBUTTON ON THE OPERATOR' PANEL. THE PUMP SHALL START AND REMAIN IN OPERATION SUBJECT TO THE ABOVE ALARM CONDITIONS LISTED ABOVE. TO END THE TRANSFER OPERATION. DEPRESS THE "STOP" PUSHBUTTON ON THE OPERATOR'S PANEL.
- 7. TO CONDUCT A TRUCK FILL OPERATION, ALIGN THE MANUAL VALVES TO ALLOW A TRANSFER FROM THE SOURCE TANK TO THE TRUCK FILLSTANDS. ON THE OPERATOR'S PANEL, TURN DESIRED TANK SELECTOR SWITCH TO "ISSUE" AND THE PUMP SELECTOR SWITCH TO "TRUCK FILL". SELECT THE DESTINATION FILLSTAND BY CHOOSING EITHER "RIGHT" OR "LEFT" ON THE SELECTOR SWITCH AT THE TRUCK FILLSTAND ISLAND. CONNECT THE SCULLY SYSTEM OVERFILL PROTECTION PLUG AND GROUND VERIFICATION CLAMP TO THE TRUCK AND ENGAGE THE DEADMAN CONTROLLER. WITH THE PUMP H-O-A SWITCH IN "AUTO", START THE TRANSFER BY DEPRESSING THE START PUSHBUTTON ON THE TRUCK FILLSTAND. THE PUMP SHALL START AND REMAIN IN OPERATION (AND ITS ASSOCIATED INDICATOR ENERGIZED) SUBJECT TO THE ALARM CONDITIONS LISTED ABOVE . IN ADDITION, THE SCULLY SYSTEM SHALL DISABLE THE PUMP IF ANY OF THE FOLLOWING CONDITIONS ARE TRUE:
  - A. THE DEADMAN IS RELEASED B. POSITIVE GROUND IS LOST
- C. HIGH LEVEL CONDITION IS REACHED ON THE TRUCK BEING FILLED

TO END THE TRUCK FILL OPERATION, DEPRESS THE "STOP" PUSHBUTTON AT THE FILLSTAND OR RELEASE THE DEADMAN.

- 8. IF AT ANY TIME A "NO FLOW" CONDITION EXISTS FOR MORE THAN 10 SECONDS (AS INDICATED BY THE ASSOCIATED FLOW SWITCH), THE ACTIVE PUMP SHALL BE DISABLED. THE START PUSHBUTTON MUST BE DEPRESSED AGAIN TO RESTART A PUMP.
- 9. ALL FUEL TRANSFER PUMPS SHALL BE DISABLED WHEN ANY EXISTING EMERGENCY SHUTDOWN DEVICE (ESD) IS DEPRESSED. DEPRESSING AN ESD SHALL ALSO DE-ENERGIZE ALL SOLENOID PILOTS AND CLOSE ALL MOTOR OPERATED VALVES WHOSE "LOCAL/REMOTE" SELECTOR SWITCH IS IN THE "REMOTE" POSITION. THE ESD ALARM SHALL BE ANNUNCIATED AT THE PLC CONTROL PANEL ON THE TRANSFER PUMP CONTROL RACK. OPERATION OF ALL PUMPS AND VALVES SHALL BE DISCONTINUED UNTIL ALL EMERGENCY SHUTDOWN SWITCHES ARE CLEARED AND THE ALARM IS ACKNOWLEDGED.

PUMP STATION 200 EQUIPMENT SCHEDULE						
EQUIPMENT NO	EQUIPMENT NAME	EQUIPMENT DESCRIPTION				
FCV-201 FCV-202	PUMP CONTROL VALVES	NON-SURGE CHECK, FLOW CONTROL TO 37.8 L/s, THERMAL RELIEF SET TO 1035 kPA.				
PCV-200	SURGE RELIEF CONTROL VALVE	SURGE PRESSURE RELIEF REGULATOR, PRESSURE CONTROL TO 1725 kPA.				
P-201 P-202	TRANSFER PUMPS	HORIZONTAL CENTRIFUGAL, 37.8 L/s, TDH=122 M, NPSHr=4 M, 75 kW (100 HP), 3600 RPM, 480/60Hz/3ø				



PUMP STATION (200) FUELING SYSTEM AND INSTRUMENTATION DIAGRAM

> ALL DIMENSIONS WITHOUT A DECIMAL POINT ARE MILLIMETERS AND ALL THOSE WITH A DECIMAL POINT ARE METERS, UNLESS OTHERWISE NOTED

AUSTIN BROCKENBROUGH & ASSOCIATES, L.L.P. Consulting Engineers

M-601 DRAWFORM REVISION: 6 AUG 2007

BRYAN M. STRAYER

Lic. No.040268

SS/ONAL ENG

UPGRADE

STATION

MILCON

ODE ID. NO. 80091 | SIZE D

WORK ORDER NO. **859348** 


CALE: AS NOTED


CONSTR. CONTR. NO.


JOB ORDER NO.


AL FACILITIES ENGINE NG COMMAN


12556448











	CIRCUIT SCHEDULE							
CKT NO	SOURCE	DESTINATION	CONDUCTORS	CONDUIT	REMARKS			
S101	S105	P-201 STARTER	3#2/0, #4 NEUT	53				
S102	S105	P-202 STARTER	3#2/0, #4 NEUT	53				
S103	STARTER P-201	PUMP P-201	3#2/0, #6 GND, 4#12	53	MOTOR WINDING HEATER, THERMOSTAT			
S104	STARTER P-202	PUMP P-202	3#2/0, #6 GND, 4#12	53	MOTOR WINDING HEATER, THERMOSTAT			
S105	EXISTING "MDP2" FEEDER	WIREWAY	4#4/0	53	SPLICE TO EXISTING FEEDER IN NEW JB			
S106	S105	"MDP2"	4#4/0	53	TAP IN NEW WIREWAY			
S107	A2-4	PUMP PAD LIGHTS	3#12	21	CONNECT TO EXISTING SPARE CIRCUIT BREAKER			

INPUT/OUTPUT	CIRCUIT NO	WIRING	SOURCE/DESTINATION	TYPE*	REMARKS
PUMP P-201 RUN COMMAND	C125	2#12	P-201 STARTER	DO	PERMIT OR PREVENT RUN
PUMP P-201 IN HAND	C126	2#14	P-201 STARTER H-O-A SWITCH	DI	
PUMP P-201 IN AUTO	C127	2#14	P-201 STARTER H-O-A SWITCH	DI	
PUMP P-201 RUNNING	C128	2#14	P-201 MOTOR STARTER	DI	
PUMP P-202 RUN COMMAND	C129	2#12	P-202 STARTER	DO	PERMIT OR PREVENT RUN
PUMP P-202 IN HAND	C130	2#14	P-202 STARTER H-O-A SWITCH	DI	
PUMP P-202 IN AUTO	C131	2#14	P-202 STARTER H-O-A SWITCH	DI	
PUMP P-202 RUNNING	C132	2#14	P-202 MOTOR STARTER	DI	
PUMP P-201 LOW FLOW	C133	2#12	FLOW SWITCH FSL-201.02	DI	COMMON 21 mm CONDUIT BETWEEN PLC PAN
PUMP P-202 LOW FLOW	C134	2#12	FLOW SWITCH FSL-202.02	DI	AND JUNCTION BOX AT FLOW SWITCHES
PUMP START/STOP/SCULLY PERMISSIVE	C135	4#14	TRUCK LOADING STATION NO. 1 PUSH BUTTON STATION	DI	COMMON 53 mm CONDUIT BETWEEN LOADING
PUMP RUN INDICATOR LIGHT		2#14		DO	RACK EXISTING JUNCTION BOX AND PLC PANE
PUMP START/STOP/SCULLY PERMISSIVE	C136	4#14	TRUCK LOADING STATION NO. 2 PUSH BUTTON STATION	DI	
PUMP RUN INDICATOR LIGHT		2#14		DO	
LANE SELECTOR SWITCH	C137	3#14	LOADING ISLAND	DI	
EMERGENCY STOP	C138	2#14	LOADING ISLAND	DI	

\* DI = DISCRETE INPUT DO = DISCRETE OUTPUT

## PLC PROGRAMMING NOTES:

- 1. FOR SEQUENCE OF OPERATION AND REQUIRED PROGRAMMING, SEE MECHANICAL SHEETS.
- 2. FOR PLC CONNECTION POINTS SEE DRAWING E-501.

	LIGHTING FIXTURE SCHEDULE							
FIXTURE SYMBOL	SKETCH NO AND TYPE	NUMBER AND TYPE OF LAMPS	VOLTAGE	MOUNTING	REMARKS			
A	NL-28	(2) F32T8	120	SURFACE	1			

LIGHTING FIXTURE SCHEDULE NOTES:

1. COPPER-FREE ALUMINUM HOUSING WITH POLYCARBONATE LENS.

ALL DIMENSIONS WITHOUT A DECIMAL POINT ARE MILLIMETERS AND ALL THOSE WITH A DECIMAL POINT ARE MILLIMETERS, UNDER SOUTHERWISE NOTED

AUSTEN BROCKENBBOUGH & AUSTON BROCKENBBOUGH & AUSTON BROWNELL NORTH CAB DISCHARGE SAID ALL THOSE WITH A DECIMAL POINT ARE MILLIMETERS AND ALL THOSE WITH A DECIMAL POINT AND A DECIM

NATAC

CRAIG H. MATTHEWS

SSS/ONAL E

FOR COMMANDER NAVFAC

ACTIVITY - SATISFACTORY TO DATE

FIRE PROTECTION

BRANCH MANAGER

CHIEF ENG/ARCH

DES JAP DRW MHK CHK CHM

3

2

